



User Manual of Flex HV-EU Series



Email: support@renonpower.com

Official website: www.renonpower.com

Address: 5900 Balcones Drive STE 100, Austin, TX 78731, United States



Revision History

Ver.	Revise contents	Date	Reviser
A00	New Edition	2024.01.20	Doreen



CATALOG

1. About this manual	4
1.1 Applicability.....	4
1.2 Target group.....	4
1.3 Symbols used.....	4
2. Safety	4
2.1 General Safety.....	4
2.3 Explanation of symbols.....	6
3. Introduction	7
3.1 Basic features.....	7
3.2 Work modes.....	7
3.3 Terminals.....	9
3.4 Dimensions.....	10
4. Technical data	10
5. Installation	12
5.1 Unpacking.....	12
5.2 Check for transport damage.....	13
5.3 Installation precaution.....	13
5.4 Space requirement.....	14
5.5 Preparation.....	14
5.6 Installation steps.....	15
5.7 Electrical Connection.....	16
5.7.1 PV Connection.....	17
5.7.2 Battery Connection.....	18
5.7.3 AC Output Connection.....	20
5.7.4 Earth Connection.....	22
5.7.5 Communication connection.....	22
5.7.6 Multiple inverters connection.....	27
5.7.7 Relay connection.....	28
5.8 Inverter configuration.....	29
6. Operation	30
6.1 Control panel.....	30
6.2 LCD function.....	31
6.3 LCD operation.....	32
7. Troubleshooting	39
8. Decommissioning	43
8.1 Dismantling.....	43
8.2 Packing.....	43
8.3 Storage.....	43
8.4 Maintenance.....	43
8.5 Disposal.....	43



Notice

This manual contains important safety instructions that must be followed during installation and maintenance of the equipment.

Save the manual!

PLEASE READ THOROUGHLY AND SAVE MANUAL FOR FUTURE REFERENCE

Copyright Declaration

All rights to the content of this manual are owned by Renon Power Technology Co., Ltd. (here in after called as 'Renon Power'). Any corporation or individual should not plagiarize, partially or fully copy it, and reproduce or distribute it in any form or means without prior written permission from Renon Power.

Renon Power reserves the right of final interpretation. This manual may be updated according to user's or customer's feedback.

The information in this manual is subject to change without notice. Please check our website at <http://www.renonpower.com> for latest version.



1. About this manual

1.1 Applicability

Please read the product manual carefully before installation, operation or maintenance of the inverter. This manual contains important safety instructions and installation instructions that must be followed during installation and maintenance of the equipment.





R-IFH05-EU03 R-IFH06-EU03 R-IFH08-EU03 R-IFH10-A-EU03 R-IFH10-EU03

1.2 Target group

This manual is intended for qualified electrical engineers / technicians responsible for installation and commissioning of the hybrid inverter.

1.3 Symbols used

Symbols used have the following meaning:

	<p>DANGER!</p> <p>'Danger' indicates a hazard with a high level of risk that, if not avoided, will result in death or serious injury.</p>
	<p>WARNING!</p> <p>'Warning' indicates a hazard with a medium level of risk that, if not avoided, will result in death or serious injury.</p>
	<p>CAUTION!</p> <p>'Caution' indicates a hazard with a low level of risk that, if not avoided, could result in minor or moderate injury.</p>
<p>NOTICE</p>	<p>NOTICE!</p> <p>'Notice' indicates a situation that, if not avoided, could result in equipment or property damage.</p>
	<p>NOTE!</p> <p>'Note' provides tips that are valuable for the optimal operation of the product.</p>

2.Safety




2.1 General Safety

The hybrid inverter has been designed and tested strictly according to international safety regulations. Read all safety instructions carefully prior to any work and observe them at all times when working on or with the hybrid inverter. Incorrect operation or work may cause:

- Injury or death to the operator or a third party;
- Damage to the inverter or other properties.



2.2 Important safety instructions

	<p>DANGER!</p> <ul style="list-style-type: none"> ◆ PV strings will produce electrical power when exposed to sunlight and can cause lethal voltage and electric shock. ◆ Only qualified personnel should work on PV panels. ◆ Do not open lid when the inverter is operating. Unauthorized opening will void warranty and warranty claims and in most cases terminate the operating license. ◆ When lid is opened, live components will be exposed, touching these may result in death or serious injury. ◆ Operating damaged inverter can lead to hazardous situations that can result in death or serious injuries due to electric shock. ◆ Batteries store large amounts of electrical energy. Short-circuiting or incorrect installation may lead to burns or serious injuries. ◆ Lethal voltages are present at battery terminals and cables connecting to the inverter. Severe injuries or death may occur if the cables and terminals are touched. ◆ PV negative (PV-) and battery negative (BAT-) on inverter side are not grounded intentionally. Connecting PV- or BAT- to EARTH is strictly forbidden.
	<p>WARNING!</p> <ul style="list-style-type: none"> ◆ Do not disconnect PV, AC and/or battery plugs and cables while the inverter is operating. Before working on the system power down on all supplies and wait for 5 minutes to discharge. Verify that there is no voltage or current before disconnecting any plugs or cables. <p>Use personal protective equipment, including rubber gloves and protective boots during installation or maintenance.</p>
	<p>CAUTION!</p> <p>Do not touch any hot parts such as the heat sink during operation, temperature of inverter surface may exceed 60°C during operation.</p>
<p>NOTICE</p>	<p>CAUTION!</p> <ul style="list-style-type: none"> ◆ Electrical installation and maintenance must only be carried out by trained and qualified electrician, following all local regulations. ◆ Do not open inverter lid or change components without Renon Power's authorization. Unauthorized work will invalidate warranty. ◆ Operate inverter as explained in this manual, failure will damage equipment and invalidate warranty.



NOTE!

◆ Installation and maintenance must be carried out by competent electricians following all local regulations.

With an integrated universal current-sensitive residual current monitoring unit included the inverter will disconnect immediately from the mains power once a fault current with a value exceeding the limit is detected. However, if an external residual current device (RCD) is mandatory, the switch must be triggered at a residual current of 300 mA (recommended), or it can be set to other values according to local regulations. For example, in Australia, the inverter can use an additional 30 mA (type A) RCD in installations.

Anti-Islanding Effect

Islanding is a condition when grid connected PV/ batteries back feed energy into the Grid when Grid is turned off for maintenance work, putting maintenance personal at serious risk. Flex HV-EU series inverters prevent islanding through Active Frequency Drift (AFD).

2.3 Explanation of symbols

Symbols on Label:

Symbol	Explanation
	CE mark. The inverter complies with requirements of applicable CE guide-lines.
	Beware of hot surface. The inverter can be hot during operation. Avoid touching during operation.
	Danger of high voltage. Danger to life due to high voltage in the inverter!
	Danger. Risk of electric shock!
	Inverter should not be disposed off with the household waste. Disposal information can be found in this manual.
	Don't work on this inverter until it is isolated from battery, mains supply and on-site PV modules.
	Danger to life due to high voltage. Inverter holds stored energy, wait for 5 minutes to discharge before opening lid.
	Please read this manual before installation.
	RCM (Regulatory Compliance Mark) The product meets the requirements of the applicable Australian standards.



3. Introduction

3.1 Basic features

The Flex HV-EU Series hybrid inverters are designed to work with PV modules, battery, mains supply and electrical loads. Hybrid inverter helps to optimize on-site consumption, charge battery with surplus PV energy and supply energy from battery to meet load. When PV and battery energy are insufficient, mains supply will be used to support loads.




Figure 3-1 Use of Hybrid Inverters

3.2 Work modes

The Flex HV-EU Series hybrid inverter has the following work modes based on the configuration and connected equipment.

Work mode: Self-use

Priority:

PV generated energy to

- a. Meet load
- b. Charge battery
- c. Export to grid




Figure 3-2 Self-use Mode



On site consumption of PV energy is the highest priority. Excess generation is used to charge batteries, and finally export to grid.

Work mode: Feed in Use

Priority:

PV generated energy to

- a. Meet load
- b. Export to grid
- c. Charge battery




Figure 3-3 Feed in Use Mode

This mode is preferred for areas with Feed-in Tariff. PV energy is first used to meet load, excess exported to grid and finally to charge battery.

Work mode: Time of Use

Priority:

During battery charging

- a. Charge battery
- b. Meet load
- c. Buy from grid




Figure 3-4 Time of Use Mode 1

Priority:

During battery discharge

- a. Meet load
- b. Discharge battery
- c. Buy from grid




Figure 3-5 Time of Use Mode 2

This mode applies the area that has peak and economy electricity price. User can choose off-peak electricity to charge battery.



Charging may be set flexibly, and the rest of time is in self-use mode.

Work mode: Back up Use

Priority:

PV generated energy to

- a. Charge battery
- b. Meet load
- c. Buy from grid




Figure 3-6 Back up Use Mode

This mode applies to area that face frequent power outages. This mode ensures the battery will has enough energy to supply during a grid outage. The back-up load could be supported by PV and battery in the event of a blackout.



WARNING!

Ensure that the load powered is with in EPS's discharge power limit, failure will result in inverter shut down with 'Over Load' warning.

When 'over load' error is displayed, adjust load to make sure it is with the range of the EPS output, and turn inverter back on.

For nonlinear load, do pay attention to inrush power, make sure it is within the range of the EPS output.

3.3 Terminals




Figure 3-7 Terminals of the inverter

Object	Description	Object	Description
A	Communication port	F	EPS port
B	DC switch	G	Grid port
C	WIFI or 4G or Ethernet port	H	SD port(Reserve)
D	PV connectors	I	USB port
E	Battery connectors		



3.4 Dimensions




Figure 3-8 Product Size

4. Technical data

Model	R-IFH05-EU03	R-IFH06-EU03	R-IFH08-EU03	R-IFH10-A-EU03	R-IFH10-EU03
PV Input Data					
Max. Recommended PV Power (W)	7500	9000	12000	15000	15000
Max. PV Input Voltage (V)	1000				
MPPT Voltage Range (V)	160 ~ 950				
Rated PV Input voltage (V)	600				
Start-up Voltage(V)	160				
No. of MPP Trackers	2				
No. of Input Strings per Tracker	1				
Max. DC Input Current (A)	18 / 18				
Max. Short Circuit Current(A)	23 / 23				
Back feed Current to Array(A)	0				
DC Switch	Integrated				
AC Output Data					
Maximum Apparent Power (VA)	5500	6600	8800	10000	11000
Rated AC Power (W)	5000	6000	8000	10000	10000
Maximum AC Current (A)	7.6	9.1	12.2	14.4	15.2
Rated AC Current (A)	7.2	8.7	11.5	14.4	14.4
Rated AC Voltage / Range (V)	3 / N / PE, 220 / 380, 230 / 400				
Grid Frequency / Range (Hz)	50 / 60; ± 5				
Adjustable Power Factor [cos φ]	0.8 leading ~ 0.8 lagging				
Output THDi (@Rated Output)(%)	< 3				



AC Input Data					
Max .apparent AC Power (VA)	10000	12000	16000	20000	20000
Max . AC Current(A)	15.2	18.2	24.3	28.8	30.4
Rated AC Voltage / Range (V)	3 / N / PE, 220 / 380, 230 / 400				
Grid Frequency / Range (Hz)	50 / 60				
AC Inrush Current (A)	32				
Maximum Output Overcurrent Protection	40				
AC Maximum output fault current (A)	73				
Output DC(Battery)					
Battery Type	Lithium				
Battery Voltage Range (V)	160 ~ 700				
Max. Charging / Discharging Current (A)	30				
Communication Interface	CAN				
EPS Output (With Battery)					
EPS Rated Power (W)	5000	6000	8000	10000	10000
EPS Rated Voltage (V)	3 / N / PE, 220 / 380, 230 / 400				
EPS Rated Frequency (Hz)	50 / 60				
EPS Rated current (A)	7.6	9.1	12.2	14.4	15.2
Output THDi (@Rated Output)(%)	< 3				
Automatic Switch Time (ms)	≤ 20				
Peak Apparent Power, Duration (VA, s)	7500, 60	9000, 60	12000, 60	15000, 60	15000, 60
Efficiency					
Max. Efficiency (%)	98.00%	98.00%	98.00%	98.00%	98.00%
Euro Efficiency (%)	97.70%	97.70%	97.70%	97.70%	97.70%
Max. Battery Discharge Efficiency (%)	97.60%	97.60%	97.60%	97.60%	97.60%
Protection					
DC Insulation Monitoring	Integrated				
Input Reverse Polarity Protection	Integrated				
Anti-island Protection	Integrated				
Residual Current Monitoring	Integrated				
Over-heat Protection	Integrated				
AC Overcurrent Protection	Integrated				
AC Short-circuit Protection	Integrated				
AC Overvoltage Protection	Integrated				
DC Surge Protection	Type II				
AC Surge Protection	Type II				
General Data					
Size (Width * Height * Depth mm)	520 * 412 * 186				
Weight (kg)	27				
User Interface	LED + OLED				
Communication	RS485 and USB (Standard), WIFI or 4G or Ethernet (Optional)				



Operating Temperature Range (°C)	-25 ~ +60
Relative Humidity (%)	0% ~ 100%
Operating Altitude (m)	≤ 2000
Standby Self Consumption (W)	< 15
Topology	Transformerless
Pollution degree	III
Protective class	I
OVC categories	DC II / AC III
Environmental categories	Outdoor
Cooling	Natural
Protection Grades	IP65
Noise (dB)	< 35
Warranty (years)	5
Certifications & Standards	
Grid Regulation	VDE 4105, EN 50549-1, VDE 0126, CEI 0-21, EN 50549-GR, EN 50549-PL, TOR Erzeuger, EN50549-CZ, AS4777, UNE217002
Safety Regulation	IEC 62109-1, IEC 62109-2
EMC	EN/IEC 61000-6-1, EN/IEC 61000-6-3

5. Installation

5.1 Unpacking

Check the delivery for completeness. Contact your dealer at once if anything is missing.



Figure 5-1 Packaging



Object	Quantity	Description
A	1	Flex HV-EU Series inverter
B	1	Mounting Bracket
C	2	Battery Connectors (1* positive, 1*negative)
D	4	PV Connectors (2* positive, 2*negative)
E	4	PV Pin contact (2* positive, 2* negative)
F	1	AC Terminal
G	1	EPS Terminal
H	1	8P Pluggable Terminal Block
I	1	Wifi or 4G or Ethernet Module(Optional)
J	5	Ethernet RJ45 Connector
K	2	M5 Screw
L	1	Earth Terminal
M	4	Expansion tubes& Expansion screws
N	1	Energy Meter(1 *Meter & 3 *CTs)
O	1	User Manual
P	1	Quality Certificate

Open the package and inspect product, check transportation damage. Also check to ensure receipt of all accessories as listed in page 12.

The instruction manual is an integral part of the unit and should therefore be read and stored carefully for future use. It is recommended that the packaging should not be opened till the unit is delivered to installation site.

5.2 Check for transport damage

On opening packaging, inspect product for any damage, in case of concern, please contact dealer immediately.

5.3 Installation precaution

The Flex HV-EU series inverter is designed for outdoor installation (IP65).

- Do not install inverter in direct sunlight.
- Do not mount inverter on flammable material.
- Do not install inverter in areas where flammable materials are stored.
- Do not install inverter in potentially explosive areas.
- Do not install inverter during rain or high humidity (>95%).
- Provide adequate ventilation when using batteries, and also read the warning label on the bottom of the inverter.
- Install inverter where air temperature would be below 40°C. Children should not have access to inverter.
- The inverter emits a slight noise when operating, this is normal and will not affect performance.
- Mounting should not tilt more than 5 degrees.
- The inverter is heavy, ensure the mounting is strong enough to hold the weight of the inverter.
- If installed in a cabinet, closet or other small enclosed areas, sufficient air circulation must be ensured in order to dissipate heat generated by the unit.
- Please select a concrete wall with load-bearing capacity and non-flammable surface for installation.




Figure 5-2 Recommended Installation Locations

5.4 Space requirement









Figure 5-3 Minimum clearance required

5.5 Preparation

No.	Tool	Model	Function
1		Sprit level	To ensure proper install
2		Two-Speed Hammer Drill	To drill holes on the wall
3		Hammer	Hanging the bracket
4		Impact Wrench Set	Hanging the bracket



5		PV-AZM-410	Stripping plier for PV cable
6		PV-CZM-22100	Crimping plier for PV cable
7		Screwdriver	Wiring
8		RJ45 Crimping Tool	Crimping tool for RJ45 terminal
9		Crimping plier	Crimping Tool For Insulated Electrical Connectors

Lifting and Handling

The unit is heavy. Do not lift it alone.

- When lifting, ensure that the unit is firmly held to avoid risk of accidental tipping or dropping.
- Ensure that the method of lifting will not allow the unit to slip from chains, slings or turn-over from lifting devices.
- Transportation must be carried by qualified persons wearing necessary personal protection equipment.
- Do not walk or stand beneath or in the proximity of the load.
- Accessible for maintenance and repair work.
- Loading capacity and hardness of the supporting surface, load rating of mounting bracket should be at least four times the weight of the devices according to IEC62109-1. And supporting characteristics will be impaired by wear, corrosion, material fatigue or ageing. This should be calculated by inspection of the design data of supporting material and consulting construction engineer.

5.6 Installation steps

Step 1: Fix wall bracket on the wall

- Use the wall bracket as a template to mark the position of the 4 holes.




Figure 5-4 Inverter Wall Mounting

- Drill holes with $\phi 10$ drill bit carefully, make sure the holes are deep enough (at least 45mm).
- Insert anchors fully into the holes. Install wall bracket using screws provided.

Step2: Hang the Flex HV-EU inverter on the wall bracket

Lifting inverter needs at least 2 people, use the handles at the sides of the inverter.



To hang the inverter over the bracket, move the inverter close to it, slightly lower inverter making sure the 4 mounting bars on the back of the inverter is fixed well with 4 grooves on the bracket.




Figure 5-5 Wall Mount Bracket

5.7 Electrical Connection

For an overview of the connection terminals of the inverter please refer to Figure 3-7, and for other wiring details, refer to chapter 3.1.

System Connection Diagrams

Note: Diagram below is for Australia, South Africa and New Zealand where neutral line can't be switched.




Figure 5-6

Note: Diagram below is for grid system without special requirement.




Figure 5-7

Main steps to connect the Flex HV-EU series system

- PV string connection
- Battery connection
 - Battery power connection
 - Battery communication connection
- AC output connection
- EPS connection
- Earth connection
- Communication connection

5.7.1 PV Connection

Before connecting PV strings to Flex HV-EU Series hybrid inverter, ensure the following:

- The total short-circuit current of PV string must not exceed inverter's maximum DC current.
- Make sure that open circuit voltage of PV string is less than 1000V.
- PV strings are not connected to earth/grounding conductor.
- Use the right PV plugs from accessory box, Battery plugs look similar to PV plugs, do confirm before using.



WARNING!

The inverter must only be operated with PV strings with class II protection in accordance with IEC 61730, application class A. It is not allowed for the positive pole or the negative pole of the PV strings to be grounded. This can cause the inverter to be destroyed.

Connection Steps:

1. Turn off the DC switch.
2. Prepare 2.5-4mm² PV cable and PV plugs as below.
3. Strip 7mm of the conductor with stripping plier. Use a suitable stripping tool for this (e.g. "PV-AZM-410").




Figure 5-8

4. Insert striped cable into pin contact and ensure all conductor strands are captured in the pin contact.




Figure 5-9

5. Crimp pin contact by using a crimping pliers(PV-CZM-22100). Put the pin contact with striped cable into the corresponding crimping pliers and crimp the contact.

6. Insert pin contact through the cable nut to assemble into back of the male or female plug. When clicked the pin contact assembly is seated correctly.

7. Tightening the DC connector.

a. Slide the cable nut towards the back shell.

b. Rotate the cable nut to secure the cable.




Figure 5-10

8. After securing the cable tightly, align the two half connectors and join together by hand until a 'click' is felt or heard.

9. To separate the DC connector.

a. Use the specified wrench tool.

b. To separate the DC+ connector, push tool down from upside.

c. To separate the DC- connector, push tool down from the bottom side.

d. Separate the connectors by hands.

5.7.2 Battery Connection

When building an on-site consumption storage system, high voltage battery is a necessary part. The FLEX HV series inverter provides the necessary interfaces to connect the battery.



WARNING!

Make sure to select cables of the right specification. Failure could cause fire and result in death or serious injury.



1. Battery Power Cable Connection

- 1) Prepare tin-plated cables of conductor cross section of 4 to 6 mm² (AWG 10).
- 2) Strip 15mm insulation off the conductor. Use a suitable stripping tool for this (e.g. "Knipex Solar 121211").
- 3) Open spring using a screwdriver (Figure 5-11).




Figure 5-11

- 4) Carefully insert the stripped wire with twisted conductors all the way in (Figure 5-12, A). The litz wire ends have to be visible in the spring.
- 5) Close the spring. Make sure that the spring is snapped in (Figure 5-12, B).




Figure 5-12

6. Push the insert into the sleeve (Figure 5-13, C).
7. Tighten the cable gland to 2 Nm (Figure 5-12, D). Use a suitable and calibrated torque wrench of size 15. Use an open-jaw wrench, size 16, to hold the connector in place.




Figure 5-13

8. Fit the two connectors together until the connection audibly locks into place.
9. Check to make sure the connection is securely locked.
10. Separating connectors.
 - 1). Insert the screwdriver into one of the four openings(Figure 5-14, A).
 - 2). Leave the screwdriver in the opening. Pull the two connectors apart(Figure 5-14, B).




Figure 5-14

2. Battery Communication Connection

The communication interface between battery and inverter is CAN with a RJ45 connector. The Pin definitions are as below.




Figure 5-15

Pin	1	2	3	4	5	6	7	8
Function	NC	NC	NC	CANH	CANL	NC	485A	485B

Overview for all battery connections




Figure 5-16

5.7.3 AC Output Connection

Flex HV-EU series inverters have already integrated RCMU (residual current monitoring unit) inside, however if an external RCD is required, a type A RCD with rated residual current of 30mA or higher is recommended.

There are two AC terminals and the assembly steps for both are the same, just need to check one for 'Grid' another for 'EPS'. The AC cable and micro-breaker/external fuse specification for AC side of Flex HV-EU series inverter as below.



Model	R-IFH05-EU03	R-IFH06-EU03	R-IFH08-EU03	R-IFH10-A-EU03	R-IFH10-EU03
Cable(Cu)	4mm ²	4mm ²	4mm ²	4-6mm ²	4-6mm ²
Normal Load-Breaker or external fuse	10A	16A	16A	20A	20A
Grid-Breaker	20A	32A	32A	40A	40A



WARNING!

Select cables of the correct specifications.

Failure could result in in fire and lead to death or serious injury.

Don't connect the line/phase cable to 'PE' terminal, failure will result in improper operation of the inverter.

Connection Step:

1. Lead the AC cable through the cable gland and the housing.




Figure 5-17

2. Remove the cable jacket by 40 mm, and strip the wire insulation by 8 mm-15 mm.




Figure 5-18

3. Fully insert the conductors to the corresponding terminal and tighten the screws to torque of 0.8 Nm. Pull cables outward to check whether they are firmly installed.




Figure 5-19

4. Assemble the housing, the terminal block and cable gland (torque 4-5 Nm). Make sure that the rib of the terminal block and the groove on the housing engage perfectly, with a click.




Figure 5-20



5.7.4 Earth Connection

One may earth the inverter enclosure of a second earth or equipotential bonding if required under local regulations. This prevents touch current if the original protective conductor fails.


Cable size: 12AWG

Connection step:

- Strip the earthing cable insulation.
- Insert the stripped cable into the ring terminal.
- Clamp the end of the ring terminal.
- Unscrew the screw of the earthing connector.
- Attach the ring terminal on the earthing connector.

Attach the gasket on the earthing connector.

- Tighten the screw of the earthing connector.



5.7.5 Communication connection

Communication interface

The inverter has a serial communication interface besides WIFI or 4G or Ethernet(Optional). Dry contact, extended port, human and machine communication, etc., can be delivered to PC or other monitoring equipment via these interfaces.




Figure 5-22 Communication interface

1. Wifi or 4G or Ethernet

For details please refer to the WIFI or 4G or Ethernet module user manual.

2. RS485 Interface

RS485 interface PINS definition:




Figure 5-23

Pin	1	2	3	4
Function	+5V	GND	485A	485B

3. ADD Interface

ADD interface PINS definition:




Figure 5-24

Pin	1	2	3	4	5	6	7	8
Function	METER-485A	METER-485B	GENA	GENB	+5V	SHUTDOWN	Relay	GND

Meter communication: METER_485A & METER_485B----pin1 & pin2

Relay contact output for generator: GENA & GENB----pin3 & pin4

Shut down the hybrid inverter: +5V & SHUTDOWN----pin5 & pin6

Relay & GND---pin7 & pin8

4. METER

Meter port PINS definition:




Figure 5-25

Pin	1	2	3	4	5	6	7	8
Function	METER-485A	METER-485B	NC	NC	NC	NC	NC	NC

The function of meter port same as pin1 & pin2 of ADD interface.

4.1 Meter wiring diagram for Typical Energy Storage System




Figure 5-26

The Flex HV-EU series energy storage inverter adopts EASTRON SDM630MCT (40mA) smart meter. The connect steps are as follows:

- Connect the meter output "L1, L2, L3, N" to power Grid. And connect 230V AC power supply to "LA, NA" (LA -Grid L line, NA-Grid Neutral line).
- Connect the meter "TX+" "TX-" to inverter RS485 A and B of "MERER" (RJ45 PIN1 to RS485 A, RJ45 PIN2 to RS485 B), referring to Chapter 5.7.5.
- Do not connect "GND" of the meter to the ground.
- Connect meter CT1 to Grid L1, CT2 to Grid L2, CT3 to Grid L3. CT's white cable connects to S1 of the meter, and the black cable connects to S2. The CT direction must be facing to the load and inverter.

Note:

- 1) It is necessary to have the sequence of phases, CT1 must be connected to Grid phase line L1, CT2 must be connected to Grid phase line L2, CT3 must be connected to Grid phase line L3.
- 2) Please note that the CT direction must be facing to the load and inverter.
- 3) The local address and the meter address need to be set as "001" on the inverter screen. The address of the smart meter itself needs to be set to "001".

4.2 Meter wiring diagram for AC Retrofit System

Renon Hybrid inverters can be used in the following situations also. If the site already has a grid tied PV system and want to increase module capacity or provide back-up power. Additional meter between the grid-connected inverters and Flex HV-EU hybrid inverter is required. One Flex HV-EU Hybrid inverter can be connected maximum two PV systems, and in the system, the smart meter must be the EASTRON SDM630MCT (40mA).




Figure 5-27 Connect one On-Grid three-phase inverter

The connect steps are the same as in the previous chapter.

Note: The smart meter communication cable "TX+" "TX-" can also be connected to "ADD Interface" port of inverter.




Figure 5-28 Connect two On-Grid three-phase inverters

Note:

- 1) It is necessary to have the sequence of phases, CT1 must be connected to Grid phase line L1, CT2 must be connected to Grid phase line L2, CT3 must be connected to Grid phase line L3.
- 2) Please note that the CT direction must be facing to the load and inverter.



3) Connect one On-Grid three-phase inverter (Figure 5-27): The local address needs to be set as "001" on the inverter screen, and meter1 address set as "001", meter2 address set as "002". The address of meter1 itself needs to be set to "001", and meter2 needs to be set to "002".

4) Connect two On-Grid three-phase inverters (Figure 5-28): The local address needs to be set as "001" on the inverter screen, and meter1 address set as "001", meter2 address set as "002", and meter3 address set as "003". The address of meter1 itself needs to be set to "001", meter2 needs to be set to "002", and meter3 needs to be set to "003".



WARNING!

If one chooses a flexible wire, ensure the cord section is pressed on the crimping terminal before connecting it to the meter as below.



5. DRM/Ripple Control Receiver (RCR)

PINS definition:




Figure 5-29

Pin	1	2	3	4	5	6	7	8
Function	DRM1/5	DRM2/6	DRM3/7	DRM4/8	+3.3V	COM/DRM0	GND	GND

This application meets the requirements of local Australian grid code (AS/NZS 4777.2) and Germany grid code (VDE-AR-N 4105).

a) In Australian grid code, requirements for connection call for compatibility with Demand Response Enabling Devices (DRED). The DRED is controlled by a local network operator and allows to put the inverter in one of the Demand Response Modes (DRMs) defined by the standard:

- DRM 0 Operate the disconnection device.
- DRM 1 Do not consume power.
- DRM 2 Do not consume at more than 50% of rated power.
- DRM 3 Do not consume at more than 75% of rated power and source reactive power if capable.
- DRM 4 Increase power consumption (subject to constraints from other active DRMs).
- DRM 5 Do not generate power.
- DRM 6 Do not generate at more than 50% of rated power.
- DRM 7 Do not generate at more than 75% of rated power and sink reactive power if capable.
- DRM 8 Increase power generation (subject to constraints from other active DRMs).

Currently, it is mandatory to respond to DRM0, which allows the network manager to remotely decouple the installation from the distribution network.

b) In Germany grid code, this logic interface is for controlling and/or limiting the inverter's output power. The grid company uses the Ripple Control Receiver (RCR) to convert the grid dispatching signal and send it as a dry contact signal. The wiring of the



ripple control receiver dry contact cables is shown in the figure below:




Figure 5-30

K1	K2	K3	K4	Switch Operation on External RCR	Output power (in % of the Rated AC output power)
1	0	0	0	Close K1	100%
0	1	0	0	Close K2	60%
0	0	1	0	Close K3	30%
0	0	0	1	Close K4	0%

6. Parallel port

PINS definition:




Figure 5-31

Pin	1	2	3	4	5	6	7	8
Function	RS485A	RS485B	VCC	CANH	CANL	GND	SYNA	SYNB

Note: Only 4 and 5 PIN pins are used.

5.7.6 Multiple inverters connection

In system with multiple inverters, one can connect the devices in a Master/Slave configuration. In this configuration, only one energy meter is connected to the Master inverter for the system control. Users should set up the master/slave on the screen after the inverter is connected. The setting steps are in Advanced*.




Figure 5-32 System block diagram

Note: Maximum number of parallel is five.

The CAN communication port is the parallel port of the hybrid inverter(Figure 5-22).

5.7.7 Relay connection

In order to better control the load power consumption, a relay can control a contactor that will open or close in certain condition. Please choose a suitable contactor according to the +12VDC power supply by the inverter provided and field load power, e.g. the contactor types of the DATASHEET - CR2020012. Please connect the contactor to the load and power grid according to the field conditions and connect the A1 and A2 of the contactor coil to the Pin7 and Pin8 of the ADD interface of the inverter.




Figure 5-33 Relay function electrical block diagram

There are four function modes in total. See page 37 for specific settings.

1. Disable: Disable the relay function, and the load under the relay will always be out of power.



2. Manual On/Off: You can manually set the switch state of the relay.
3. Timing: The relay is on according to the setting relay switch-on start time, and it is off according to the setting relay switch-on end time. And it supports setting up to two time periods. (T1, T2).
4. Battery SOC: Under this mode, users need to set relay switch-on battery SOC, relay switch-off battery SOC delay off time.
 - RLY On BAT SOC: Relay is on if battery SOC exceeds a defined value.
 - RLY Off BAT SOC: Relay is off if battery SOC falls below a defined value.
 - Delay Off Time: The relay remains on if battery SOC falls below switch-on SOC for a defined time; the timer will reset if battery SOC exceeds switch-on SOC within a defined time. During the defined time, the relay will be off immediately if battery SOC has fallen below RLY Off BAT SOC.

5.8 Inverter configuration

Start inverter after checking all the following:

- Check that the device is fixed well on the wall.
- Make sure all the PV wiring and the AC wiring are completed.
- Make sure the meter are connected well.
- Make sure the battery is connected correctly.
- Turn on the external AC, DC switch.
- Turn on the DC switch to the 'ON' position.
- Set sysswitch on the screen of the inverter to 'Turn on'.

Starting inverter:

Inverter will start automatically when the PV panel generate enough energy or the battery is charged.

Check the status of LED and LCD screen, first LED should be green and the LCD screen should display the main interface.

If first LED is not green please check the below:

- All the connections are right.
- All the external disconnect switches are closed.
- The DC switch of the inverter is in the 'ON' position.

Enter the setting interface.

Set the safety standard as in page 35; Set the system time as in page 34; Set work mode as in page 34; Set the communication address as in page 35; Set the EPS as in page 34;



NOTE!

Please configure the inverter first time start up.

Above steps is for regular start-up of the inverter. If the inverter

is turned on for the first time, set the language, time, and safety regulations in turn according to the boot guidance.



6. Operation

6.1 Control panel





Figure 6-1


Object	Name	Description
A	Indicator LED	Green: Normal working Status.
B		Red: Fault.
C		Blue: Battery communication status.
D		Yellow: RS485 communication status.
E	Function Button	ESC button: Leave from current interface or function.
F		Up button: Move cursor to increase value.
G		Down button: Move cursor to decrease value.
H		OK button: Confirm the selection.
I	LCD Screen	Display the information of the inverter.



6.2 LCD function

Menu structure:





6.3 LCD operation

1. Main screen

The main screen as below. Press up or down for more information.




2. Status

Press 'OK' to enter the menu, check grid , solar, battery, EPS and temperature of the inverter. Press up and down to select, press




'ESC' to return to the Menu.



2.1) Solar


This status shows the real time PV parameters of the system. The input voltage, current and power of each PV input. Press up and down button to review the parameter. Press 'ESC' to return to status.



2.2) Grid


This status shows the real time grid parameters such as voltage, current, output power and frequency. Pac measures the output of the inverter.

Press up and down button to review the parameter. Press 'ESC' to return to status.




2.3) Meter

This status shows the meter situation of the system. Include the smart meter A, B, and C phase power and total power. Press up and down button to review the parameter. Press 'ESC' to return to Status.




2.4) Charger

This status shows the charger situation of the system. Include the battery voltage, charge or discharge current. Charge or discharge power. '+' means in charging; '-' means in discharging. Press up and down button to review the parameter. Press 'ESC' to return to Status.




2.5) BMS

This status shows the battery situation of the system. Include the battery voltage and current, charge and discharge voltage, charge and discharge current. '+' means in charging; '-' means in discharging. Press up and down button to review the parameter. Press 'ESC' to return to Status.




2.6) EPS

EPS will only have data when the inverter is working in EPS mode, it will show the real time data of the EPS output, as voltage , current, power, frequency. Press up and down button to review the parameter. Press 'ESC' to return to Status.



3. History

The history function contains three aspects of the information: inverter yield, battery yield and error log. Press up and down to select, and review the data of system, press 'ESC' to return to the Menu.



4. Settings

Setting function is used for set the inverter for language, date and time, work mode, communication address, advanced and so on.


4.1) Language

Press up or down button to change language. Press 'OK' to confirm.




4.2) Date Time

Press up or down button to change date and time. Press 'OK' to confirm.



4.3) Work Mode


Press up or down button to select different work modes. Press 'OK' to confirm.






4.4) Communication Address

Press up or down button to change address of local and meter. Press 'OK' to confirm.




4.5) Advanced settings require the original password '0000', Press 'OK' to confirm.



4.5.1) On-Grid

Press up or down button to set the grid functions. Press 'OK' to confirm.




4.5.1.1) Safety

Press up or down button to change the grid code. Press 'OK' to confirm.




4.5.1.2) Grid

Press up or down button to change the value of grid voltage and grid frequency protect. Press 'OK' to confirm.



4.5.1.3) Export control

With this function the inverter can control the energy export to the grid. Press up or down button to change the export power. Press 'OK' to confirm.




4.5.1.4) Phase unbal

When the system is connected with three-phase unbalanced load or single-phase load, customers can enable the phase unbalance function, the inverter can detect and identify the three-phase current unbalance in the system through the meter and output unbalanced power to different phase.



4.5.2) Battery

Press up or down button to set the parameters of battery. 'Eps BT Low Rec' means recovery enable switch when battery low capacity in EPS mode, 'Eps OL Rec SOC' means EPS overload due to low capacity for battery, if recovered, min soc. Press 'OK' to confirm.



4.5.3) Bat Model


Press up or down button to set the model of battery. Press 'OK' to confirm.






4.5.4) Relay Function

Press up or down button to set the relay function. Press 'OK' to confirm.



4.5.5) Feature

Press up or down button to enable or disable Remote Control, DRM0, RCR, Meter Setting, and Bypass Relay. Press 'OK' to confirm.




4.5.6) New Password

Press up or down button to set new password. Press 'OK' for more than 3 seconds to confirm.




4.5.7) Reset

Press up or down button to reset energy, reset errors or factory reset. Press 'OK' to confirm.




4.5.8) USB

Press up or down button to upgrade DSPM, DSPS, ARMC, BATM or BATS. Press 'OK' to confirm.




5. System Switch

Press up or down button to turn on or turn off the inverter. Press 'OK' to confirm.



6. About

This interface shows the information of the inverter, such as series number and software version.




7. Self-Test in accordance with CEI 0-21 (Applies to Italy only)

The self-test is only required for inverters, which are commissioned in Italy. The Italian standard requires that all inverters feeding into the utility grid are equipped with a self-test function in accordance with CEI 0-21. Please note that there is a self-test option only when the inverter selects CEI 0-21. During the self-test, the inverter will consecutively check the protection reaction times and values for overvoltage, under voltage, over frequency and under frequency. Self-test function is available at any time. It also allows end user get test reports shown on LCD display.

Note: Users need to set the inverter country to CEI 0-21 before testing.

Auto-Test from screen:



7. Troubleshooting

This section contains information and procedures for solving possible problems with the Flex HV-EU series inverters, and provides you with trouble shooting tips to identify and solve most problems that could occur with the Flex HV-EU series inverters. This section will help you narrow down the source of any problems you may encounter. Please read the following troubleshooting steps.

- Check the warning or fault messages on the System Control Panel or Fault codes on the inverter information panel. If a message is displayed, record it before doing anything further.
- Attempt the solution indicated in below table.

HW Protect Fault	Inverter over current or battery over current or PV over current detected by hardware. <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
Grid Lost Fault	Grid is lost. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state.
Grid Volt Fault	Grid voltage out of range. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state.
Grid Freq Fault	Grid frequency out of range. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal.



	<ul style="list-style-type: none"> • Or seek help from us, if not go back to normal state.
PV Volt Fault	<p>PV voltage out of range.</p> <ul style="list-style-type: none"> • Please check the output voltage of PV panels. • Or seek for help from us.
Bus Volt Fault	<p>Bus voltage out of range detected by hardware.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
Bat Volt Fault	<p>Battery voltage fault.</p> <ul style="list-style-type: none"> • Check if the battery input voltage is within the normal range. • Or seek help from us.
Vgrid 10M Fault	<p>The grid voltage is out of range for the last 10 Minutes.</p> <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state.
DCI OCP Fault	<p>DC component is out of limit in output current.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
DCV OVP Fault	<p>DC component is out of limit in output voltage.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
SW OCP Fault	<p>Output current high detected by software.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
RC OCP Fault	<p>The residual current is high.</p> <ul style="list-style-type: none"> • Please check if the insulation of electric wires is damaged. • Wait for a while to check if back to normal. • Or seek for help from us.
Iso Check Fault	<p>The isolation is failed.</p> <ul style="list-style-type: none"> • Please check if the insulation of electric wires is damaged. • Wait for a while to check if back to normal. • Or seek for help from us.
Temp Over Fault	<p>The inverter temperature is high.</p> <ul style="list-style-type: none"> • Please check if the environment temperature. • Wait for a while to check if back to normal. • Or seek for help from us.
BatConDir Fault	<p>The battery connection is reversed.</p> <ul style="list-style-type: none"> • Check if the positive pole and negative pole of battery are correctly connected. • Or seek help from us.
AD Sample Fault	<p>The sample value between master and slave is not consistent.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
EPS Over Load	<p>Over load in off grid mode.</p> <ul style="list-style-type: none"> • Please check if the eps load power exceeds the limit. • Or seek for help from us.
Bat Low Fault	<p>The battery power is low.</p>



	<ul style="list-style-type: none"> • Wait the battery to be recharged. • Or seek for help from us.
ByPassRelay Fault	<p>By pass relay fault.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
SPI Comm Fault	<p>The communication between master and slave fault</p> <ul style="list-style-type: none"> • Disconnect solar power PV+ , PV- and battery, reconnect them. • Or seek help from us, if cannot go back to normal state.
BMS_Lost	<p>The communication between BMS and Inverter is interrupted.</p> <ul style="list-style-type: none"> • Check if the communication cable between BMS and Inverter is correctly and well connected.
Inter Fan Fault	<p>Fan Device Fault.</p> <ul style="list-style-type: none"> • Disconnect solar power PV+ , PV- and battery, reconnect them. • Check if the fan is stopped by dust or other foreign. • Or seek help from us, if cannot go back to normal state.
AC HCT Fault	<p>AC Current Sensor Fault.</p> <ul style="list-style-type: none"> • Disconnect solar power PV+ , PV- and battery, reconnect them. • Or seek help from us, if cannot go back to normal state.
Inv EEPROM Fault	<p>The master eeprom is fault.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
GFCI HW Fault	<p>The residual current circuit is fault.</p> <ul style="list-style-type: none"> • Please check if the insulation of electric wires is damaged. • Wait for a while to check if back to normal. • Or seek for help from us.
EPS Relay Fault	<p>The EPS relay always keep open.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
Grid Relay Fault	<p>The grid relay always keep close.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
Other Dev Fault	<p>Other device fault.</p> <ul style="list-style-type: none"> • Turn off the PV, battery and grid , reconnect them. • Or seek for help from us if cannot back to normal.
Mgr EEPROM Fault	<p>The manager eeprom is fault.</p> <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
Meter Lost Fault	<p>The communication between meter and Inverter is interrupted.</p> <ul style="list-style-type: none"> • Check if the communication cable between meter and Inverter is correctly and well connected.
Dsp Lost Fault	<p>SCI communication fault.</p> <ul style="list-style-type: none"> • Disconnect solar power PV+, PV- and battery, reconnect them. • Or seek help from us, if cannot go back to normal state.
BMS Volt Fault	<p>Battery voltage sensor error.</p>



	<ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Tepr Fault	<p>Battery temperature sensor error.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS IN_COM Fault	<p>BMS internal communication fault.</p> <ul style="list-style-type: none"> • Disconnect battery, check wiring between inverter and battery, battery internal wiring then reconnect. • Or seek help from us, if not go back to normal state.
BMS Dcov Fault	<p>Battery input over voltage error.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS RV Fault	<p>Battery input transposition error.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Relay Fault	<p>The battery relay is fault.</p> <ul style="list-style-type: none"> • Disconnect battery, then reconnect. • Or seek help from us, if not go back to normal state.
BMS Cell Fault	<p>Battery cell error.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Other Fault	<p>Battery other error.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect OV	<p>Battery over voltage protect.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect LV	<p>Battery under voltage protect.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect ChrOC	<p>Battery over current charging protect.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect DischargeOC	<p>Battery over current discharging protect.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect TemHigh	<p>Battery temperature is high.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.
BMS Protect TemLow	<p>Battery temperature is low.</p> <ul style="list-style-type: none"> • Wait for 5 minutes, check again. • Or seek help from us, if not go back to normal state.

Remark

If your inverter's information panel is not displaying a Fault light, check the following to make sure that the present state of the



installation allows proper operation of the unit.

- Is the inverter located in a clean, dry, and adequately ventilated place?
- Have the DC input breakers been opened?
- Are the cables adequately sized and short enough?
- Are the input and output connections and wiring in good condition?
- Are the configurations settings correct for your particular installation?
- Are the display panel and the communications cable are properly connected and undamaged?

Contact Renon Power Customer Service for further assistance. Please be prepared to describe details of your system installation and provide the model and serial number of the unit.

8. Decommissioning

8.1 Dismantling

- Disconnect the inverter from DC input and AC output.
- Disconnect battery wiring.
- Wait for 5 minutes for de-energizing.
- Disconnect communication and optional connection wiring.
- Remove the inverter from the bracket.

8.2 Packing

If possible, please pack the inverter in the original packaging.

If it is no longer available, you can also use an equivalent carton that meets the following requirements.

- Suitable for loads more than 27kg.
- With handle.
- Can be fully closed.

8.3 Storage

Store the inverter in dry place where ambient temperatures are always between -20°C - $+60^{\circ}\text{C}$.

8.4 Maintenance

Inverters generally do not need any daily or routine maintenance. Heat sink should not be blocked by dust, dirt or any other items. Before the cleaning, make sure that the DC SWITCH is turned OFF and the circuit breaker between inverter and electrical grid is turned OFF. Wait at least for 5 minutes before the Cleaning.

- Check that if the cooling fins on the rear are covered by dirt, if yes, fins should be cleaned. This shall be done at regular intervals.
- Check whether the indicators of the inverter are in normal state, check whether the keys of the inverter buttons are in normal state, check whether the display of the inverter is normal. These checks should be performed at least every 6 months.
- Check the input and output wires for damages or aging. This check should be performed at least every 6 months.
- You should keep the inverter panels clean and their security checked at least every 6 months.

8.5 Disposal

When the inverter or other related components need to be disposed, have it carried out according to local waste handling regulations. For safe disposal, take inverter to appropriate waste recycling center in your local area.



Energy storage system
solutions experts!

RENON POWER TECHNOLOGY INC.

